

4C Dimension and Weight Chart

SUITE A 39" UNIT HEIGHT	ROUGH OPENING HEIGHT: 38-1/16"; ROUGH OPENING DEPTH: 17" Minimum			* Weights shown for both Front-load / Rear-load option					
	MODEL	RO WIDTH	ACTUAL WIDTH	WEIGHT (LBS)*	# TENANTS	# PARCELS			
SUITE A 39" UNIT HEIGHT	4CAT8-19	30-5/16"	31-9/16"	120 / 143	19	0			
	4CAT2-15	30-5/16"	31-9/16"	115 / 138	15	1			
	4CAT1-4	16-1/4"	17-1/2"	63 / 74	4	1			
	4CAT6-9	16-1/4"	17-1/2"	67 / 78	9	0			
	4CAT10	16-1/4"	17-1/2"	55 / 72	0	2			
	4CAT6-XL	16-1/4"	17-1/2"	63 / 76	3	0			
SUITE B 18" UNIT HEIGHT	ROUGH OPENING HEIGHT: 17-1/16"; ROUGH OPENING DEPTH: 17" Minimum			MODEL	RO WIDTH	ACTUAL WIDTH	WEIGHT (LBS)*	# TENANTS	# PARCELS
	4CBT8-7	30-5/16"	31-9/16"	55 / 63	7	0			
	4CBT2-3	30-5/16"	31-9/16"	55 / 65	3	1			
	4CBT6-3	16-1/4"	17-1/2"	30 / 33	3	0			
	4CBT10	16-1/4"	17-1/2"	25 / 32	0	1			
	4CBT10-2	30-5/16"	31-9/16"	50 / 65	0	2			
	4CBT8-XL	30-5/16"	31-9/16"	55 / 64	4	0			
SUITE C 51-1/4" UNIT HEIGHT	ROUGH OPENING HEIGHT: 50-5/16"; ROUGH OPENING DEPTH: 17" Minimum			MODEL	RO WIDTH	ACTUAL WIDTH	WEIGHT (LBS)*	# TENANTS	# PARCELS
	4CCT2-16	30-5/16"	31-9/16"	145 / 175	16	2			
	4CCT1-7	16-1/4"	17-1/2"	76 / 91	7	1			
	4CCT10	16-1/4"	17-1/2"	67 / 86	0	3			
	4CCT2-XL	30-5/16"	31-9/16"	145 / 182	6	2			
SUITE D 21-1/2" UNIT HEIGHT	ROUGH OPENING HEIGHT: 20-9/16"; ROUGH OPENING DEPTH: 17" Minimum			MODEL	RO WIDTH	ACTUAL WIDTH	WEIGHT (LBS)*	# TENANTS	# PARCELS
	4CDT8-9	30-5/16"	31-9/16"	68 / 78	9	0			
	4CDT2-5	30-5/16"	31-9/16"	60 / 73	5	1			
	4CDT2-4	30-5/16"	31-9/16"	61 / 73	4	1			
	4CDT6-4	16-1/4"	17-1/2"	40 / 45	4	0			
	4CDT10	16-1/4"	17-1/2"	40 / 52	0	1			
	4CDT6-XL	16-1/4"	17-1/2"	40 / 45	2	0			
SUITE E 28-1/2" UNIT HEIGHT	ROUGH OPENING HEIGHT: 27-9/16"; ROUGH OPENING DEPTH: 17" Minimum			MODEL	RO WIDTH	ACTUAL WIDTH	WEIGHT (LBS)*	# TENANTS	# PARCELS
	4CET8-13	30-5/16"	31-9/16"	86 / 101	13	0			
	4CET2-9	30-5/16"	31-9/16"	86 / 103	9	1			
	4CET1-1	16-1/4"	17-1/2"	58 / 67	1	1			
	4CET6-6	16-1/4"	17-1/2"	58 / 67	6	0			
	4CET6-XL	16-1/4"	17-1/2"	58 / 67	3	0			
SUITE F 56-1/2" UNIT HEIGHT	ROUGH OPENING HEIGHT: 55-9/16"; ROUGH OPENING DEPTH: 17" Minimum			MODEL	RO WIDTH	ACTUAL WIDTH	WEIGHT (LBS)*	# TENANTS	# PARCELS
	4CFT1-9	16-1/4"	17-1/2"	97 / 119	9	1			
	4CFT2-20	30-5/16"	31-9/16"	171 / 206	20	2			
SUITE G 54-3/4" UNIT HEIGHT	ROUGH OPENING HEIGHT: 53-13/16"; ROUGH OPENING DEPTH: 17" Minimum			MODEL	RO WIDTH	ACTUAL WIDTH	WEIGHT (LBS)*	# TENANTS	# PARCELS
	4CGT1-9	16-1/4"	17-1/2"	97 / 117	9	1			
	4CGT2-19	30-5/16"	31-9/16"	171 / 206	19	2			
SUITE H 40-3/4" UNIT HEIGHT	ROUGH OPENING HEIGHT: 39-13/16"; ROUGH OPENING DEPTH: 17" Minimum			MODEL	RO WIDTH	ACTUAL WIDTH	WEIGHT (LBS)*	# TENANTS	# PARCELS
	4CHT2-15	30-5/16"	31-9/16"	122 / 145	15	1			
	4CHT8-20	30-5/16"	31-9/16"	123 / 145	20	0			
	4CHT1-4	16-1/4"	17-1/2"	66 / 77	4	1			
	4CHT6-9	16-1/4"	17-1/2"	68 / 79	9	0			
	4CHT10	16-1/4"	17-1/2"	52 / 69	0	2			
SUITE I 37-1/4" UNIT HEIGHT	ROUGH OPENING HEIGHT: 36-5/16"; ROUGH OPENING DEPTH: 17" Minimum			MODEL	RO WIDTH	ACTUAL WIDTH	WEIGHT (LBS)*	# TENANTS	# PARCELS
	4CIT1-4	16-1/4"	17-1/2"	55 / 69	4	1			
	4CIT2-9	30-5/16"	31-9/16"	96 / 127	9	2			

Rough opening (RO) height and width on all models tolerant to +1/4"-0". RO height and width on all multi-unit installations tolerant to +1/8"-0".

Use this formula to calculate the rough opening width for Multi-Unit 4C Installation = (the sum of all actual unit widths) - 1-1/8"